


# KENWOOD

## Microwave / Combination Oven



# K28CB10



**DSG Retail Limited is responsible for after sales service.**  
**If you have a query about the product please contact our product support line**  
**0844 561 6263 (Currys) and 08700 118 117 (Pixmania).**

# table of contents

<b>table of contents</b>	<b>2 - 3</b>
<b>know your Kenwood microwave</b>	<b>4</b>
<b>safety information</b>	<b>4 - 8</b>
<b>using aluminium foil in your microwave</b>	<b>9</b>
<b>unpacking and getting ready</b>	<b>10</b>
<b>introducing microwave cooking</b>	<b>11 - 16</b>
cooking with a microwave	11 - 12
microwave heating categories	13
<hr/>	
<b>microwave cooking</b>	<b>19</b>
<b>grill or combination cooking</b>	<b>20-21</b>
<b>convection cooking (with preheating)</b>	<b>22</b>
<b>convection cooking (without preheating)</b>	<b>23</b>
<b>two-stage cooking</b>	<b>24</b>
<b>memory programme cooking</b>	<b>25</b>
<b>auto cooking</b>	<b>26-27</b>
auto menu	26-27
<b>reheating</b>	<b>28</b>
<b>defrosting</b>	<b>29</b>
defrost by time	29
defrost by weight	29
defrosting ground meat	30
defrosting seafood	30
<b>querying the cooking function</b>	<b>31</b>
to find out the cooking power	31
<hr/>	
<b>cleaning your microwave</b>	<b>32 - 33</b>
<b>troubleshooting</b>	<b>34 - 35</b>
questions and answers	34 - 35
<b>specification</b>	<b>36</b>

steam	14
condensation	14
product overview	14 - 15
control panel overview	15
checking your microwave	16
<b>clock setting</b>	<b>17</b>
<b>setting the child lock</b>	<b>18</b>

**before use**

---

to find out the time	31
<b>kitchen timer function</b>	<b>31</b>

**operating instructions**

**care, maintenance and  
troubleshooting**

# know your Kenwood microwave

## **before using your Kenwood microwave**

- Read these instructions carefully and retain for future reference.
- Remove all packaging labels and dispose of them properly.

## **before calling for service**

- Review this section on Troubleshooting. This will help you to solve general problems yourself.

# safety information

## **general safety**

- Switch off and unplug before fitting or removing tools/ attachments, after use and before cleaning.
- Keep your fingers away from moving parts and fitted attachments.
- Never use a damaged machine.
- Never operate the machine when it is empty.
- Keep mains cable of reach from children.
- Keep power unit, mains cable and plug away from water.
- Never exceed the maximum capacities.
- When using an attachment, read the safety instructions.
- Take care when lifting this appliance as it is heavy.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Only use the appliance for its intended domestic use. The company responsible for this product, DSG Retail Limited, will not accept any liability if the appliance is subject to improper use, or failure to comply with these instructions.

# safety information

**please read carefully and keep for future reference**

## **maintenance of your microwave**

**WARNING**  : *It is hazardous for anyone other than a qualified technician to carry out any service or repair operation which involves the removal of a cover that gives protection against exposure to microwave energy.*

**WARNING**  : If the door or door seals are damaged, the oven must not be operated until it has been repaired by a qualified technician.

- If smoke is observed, switch off and unplug the appliance and keep the door closed in order to contain the flames.
- If the mains cable is damaged, it must be replaced by a service agent or similar qualified technician.
- If you have a pacemaker, please contact your doctor before using a microwave oven.

## **microwave use**

- This microwave is not intended for commercial use.
- It should never be used for drying clothes or other non-food purposes.
- The appliance is not intended to be operated by means of an external timer or separate remote-control system.
- The microwave should not be left unattended when in use.
- The temperature of accessible surfaces may be high when the appliance is operating.
- To prevent high moisture content gathering inside the oven cavity, open the door immediately after the cooking function has stopped to allow steam to escape.
- Only use utensils that are suitable for microwave use.
- Care should be taken so metal objects are not used in the microwave.
  - These include :
    - “ Metal cooking utensils
    - “ Metal plates or trays
    - “ Wire twist ties
    - “ Crockery with metal trims
    - “ Meat thermometer
- Care should be taken when using paper, plastic, wooden or other combustible materials in the oven as they can catch fire.
- Oil & fat for deep frying should not be heated in the microwave.
- Only use cling film designed for microwave use & take extra care when removing the film to avoid steam burns.
- Only heat popcorn that has been designed for microwave use.

# safety information

## **cooking use**

*As the power of different microwave ovens can vary considerably, care must be taken when first using this appliance as it may cook faster than expected.*

- Do not leave the appliance unattended during use.

**WARNING**  : Only allow children to use the oven without supervision when adequate instructions have been given so that the child is able to use the oven in a safe way and understands the hazards of improper use; DO NOT assume that because a child has mastered one cooking skill he/she can cook everything without close supervision. The microwave MUST NOT be treated nor used like a toy.

- Take care when cooking food with a high sugar or fat content, such as Christmas pudding or fruitcake. The sugar or fat can overheat and in some cases catch fire.

## **fire!**

*In the event of fire:*

- Keep the oven door closed.
- Turn off the power.
- Unplug the appliance from the mains power.

## **first aid**

*Treat scalding by:*

- Quickly placing the scald under cold running water for at least 10 minutes.
- Cover with a clean dry dressing. Do not use creams, oils or lotions.

## **cleaning your microwave**

*The microwave should be cleaned regularly and food deposits removed. Failure to maintain the oven in a clean condition can affect the life of the appliance and possibly result in a hazardous situation. (See cleaning your microwave)*

# safety information

## **do not use these in your microwave**

- Never use equipment made of metal, except foil in your microwave. The microwave energy cannot pass through the metal so it bounces off and sparks against the inside of the oven.
- Stop the microwave straight away if any equipment does cause sparks.
- Remember that some crockery has a metal trim around the edge. Even this trim can cause sparks.

## **Containers / Certain foods**

**WARNING**  : Pressure will build up in sealed containers and cause them to explode. Therefore, do not use the following in your microwave:

- Sealed containers
  - Capped bottles
  - Vacuum containers
  - Sealed jars
  - Hard-boiled eggs
  - Eggs in their shells
  - Nuts
- Always pierce the skin of fruit and vegetables, such as potatoes.
  - Never use scratched, cracked or damaged glass in a microwave. Damaged glass can explode.

## **delayed boiling**

*Liquids heated in a microwave can boil up when removing them from the microwave.*

*Take the following precautions :*

- Always stir liquids, before and after cooking.
- Allow them to stand.
- Use containers that are wider at the top than the bottom.

## **preparing food for babies**

*Extra care must be taken when preparing food or drink for babies and small children.*

- Always test the food or liquid temperature before giving it to a baby.
- When using a baby bottle, ensure the teat is removed before heating.
- When warming milk, ensure the bottle is shaken.

## **caution!**

*During cooking, the outer surface will become hot, do not touch outer casing of the microwave. Care should be taken not to store any items on top of your microwave.*

# safety information



## earthing instructions

- **WARNING: THIS APPLIANCE MUST BE EARTHED.**
- **This appliance is equipped with a mains cable having an equipment-earthing conductor and an earthing plug.**
- The plug must be plugged into an appropriate outlet that is installed and earthed in accordance with all local standards and requirements.

## warning!

- Improper connection of the equipment-earthing conductor can result in a risk of electric shock.
- The wires in the cord are coloured as follows:
  - Green and Yellow = Earth,
  - Blue = Neutral,
  - Brown = Live.
- Check with a qualified electrician or service representative if you are in doubt whether the appliance is properly earthed.
- Never modify the plug provided with the appliance.
- If the plug does not fit properly in the outlet, have a qualified electrician install the correct one.

# using aluminium foil in your microwave

*It is safe to use aluminium foil in your microwave as long as you follow these safety guidelines.*

As with all metal, microwave energy cannot pass through foil, but provided that you keep the foil away from the side of the oven it will not cause sparks and there will not be any damage to your oven.

Using foil is a good way of shielding parts of food that you do not want to cook as quickly as others – perhaps where the food is thinner and would otherwise overcook.

Place the foil over the area you want to shield, taking care that the foil will not touch the sides of the oven when the turntable rotates. Only use one piece of foil at a time so that you do not get sparks between the separate pieces.

Follow these guidelines when using foil in your microwave:


- Remove foil lids from containers before using in the microwave. Some lids are made of card with a foil covering – these should be removed too. Use a microwave safe transparent lid if possible.
- Stir food during cooking if the container has a lid or film cover.
- Always use the glass turntable.
- Use shallow containers with a large surface area. Do not use containers that are more than 1.25in (3.5cm) deep.
- Use oven gloves when handling hot foil containers.
- Do not completely cover food with foil. The microwave energy cannot pass through the foil so the food will not cook.
- Do not let aluminium foil touch the inside of the oven.
- Do not use more than one piece of foil in the oven at the same time.

# unpacking and getting ready

*This microwave is designed for home use. It should not be used for commercial catering.*


1. After unpacking your microwave, check that it has not been damaged whilst in the box. Make sure there are no dents on the oven, and the door closes properly. A dented or damaged oven could allow microwave energy to escape. Make sure that you have taken all the packaging from inside the microwave. Please dispose of the plastic wrappings or bags safely and keep out of the reach of babies and young children.

2. Choose a flat work surface for your microwave away from heat sources such as radiators or fires and away from cold areas. You should allow a 10cm space all around the oven and 30cm above so that warm air can escape from the vents during cooking – This microwave is not designed to be built in. ①



3. Plug your microwave into a standard household electrical socket (230-240 volt, 13 amp rated). Avoid using a socket that also has an adaptor and other equipment plugged in. Do not use a multi-adaptor.

4. Put the turntable ring inside the microwave and place the glass turntable on top of the ring. ②  
The turntable is shaped to sit securely on the spindle. You must always use the turntable and ring whenever you use the microwave.



# introducing microwave cooking

*Always remember the basic safeguards you would follow when using any cooking equipment or handling hot food.*

*See below for basic guidelines in microwave cooking.*


*If you are unfamiliar with using a microwave, refer to the back of this instruction booklet for more information.*

## cooking with a microwave

- Cooking with a microwave is much faster than conventional cooking and, whilst you should make sure that food is fully cooked, you should be careful not to overcook it.
- Microwave energy can heat unevenly so stirring to distribute heat is very important. Always stir from the outside, inwards.
- If you are cooking a number of individual foods at the same time, such as baked potatoes or small cakes, arrange them evenly on the turntable so that they cook evenly. Never stack food in your microwave.
- Turn larger foods such as meat roasts and poultry during cooking so that the top and bottom cook evenly. It is also recommended to turn pieces of meat or poultry, especially if they contain a bone.
- Meat and poultry which is cooked for 15 minutes or more will brown lightly in its own fat. Anything cooked for a shorter time can be brushed with a browning sauce to give an appetising colour.
- Strips of aluminium foil can be used to cover the thinner pieces of food to stop them overcooking before the thicker parts of the food have had a chance to cook. Use the foil sparingly and wrap around the food or container carefully to stop it touching the inside of the oven which could cause sparks.

**NOTE:** You should always have your microwave checked by a qualified technician if it has been dropped or damaged to ensure it is safe to use.

- Microwave ovens cook food using microwave energy that is similar to naturally occurring radio waves. Normally, these “waves” would fade as they dispersed into the atmosphere but in a microwave oven they are concentrated onto the food causing it to heat up.
- Microwave energy cannot pass through metal – so it cannot escape from inside your microwave oven – but it can pass through materials like glass, porcelain, plastic and paper. These materials are used in the manufacture of microwave safe cooking equipment.
- Microwave safe cooking equipment will still get hot as the food it contains heats up.



*The microwave energy focuses on the moisture in the food causing lots of tiny vibrations. The vibrations get so great that the moisture, and the food heats up. (Fig 1)*

## checking your cooking utensils

*Most heat-resistant, non-metallic cooking utensils are safe to use in your microwave. If you are not sure if you can use a utensil in your microwave, follow this simple test:*

1. Put the utensil into the microwave next to a cup of water – use a cup that you know is microwave safe. Close the door.
2. Turn the microwave oven on for 30 seconds only.
3. After 30 seconds, carefully check to see if the water has warmed up.  
If the water has not warmed up but the utensil has, the utensil is not microwave-safe and should not be used in the microwave.
4. Do not use your hands to touch the utensils as it may already be hot.

**NOTE:** Your microwave comes with a microwave safe grill rack. If you want to use another grill rack, please carry out this test to ensure that it is microwave safe.

## microwave heating categories

Your microwave has been tested and labelled to meet the government's voluntary agreement on the reheating of pre-cooked food.

The heating characteristics and output power levels of microwave ovens are usually calculated using a relatively large portion of food (a 1000 gram load, IEC 705) but many packs of pre-cooked food are sold in smaller packs, often about 350 grams. The government, in partnership with food companies and microwave manufacturers, have set up a system of heating categories to help you choose the reheating time for pre-cooked food.



900W is the output power of the microwave oven.

E is the heating category for your microwave oven. Check the cooking times for category E on the food's packaging to see how long it should be cooked for. Please see below example for reference.

To Microwave:  
Remove outer packaging.  
Pierce film lid SEVERAL TIMES.  
Place on a microwaveable plate.  
Heat on full power.  
Stir or Turn halfway through heating.

To Microwave from frozen:  
Remove outer packaging.  
Pierce film lid SEVERAL TIMES.  
Place on a microwaveable plate.  
Heat on full power.  
Stir or Turn halfway through heating.


	Heating Category		Wattage (IEC 705)	
	B	D	650W	750W
	B	D	650W	750W
Full power (in minutes)	2	2	2	2
Stir / Turn	Stir / Turn		Stir / Turn	
Full power (in minutes)	2	1.5	2	1.5
Standing time (in minutes)	1	1	1	1

	Heating Category		Wattage (IEC 705)	
	B	D	650W	750W
	B	D	650W	750W
Full power (in minutes)	3	2.5	3	2.5
Stir / Turn	Stir / Turn		Stir / Turn	
Full power (in minutes)	4	3.5	4	3.5
Standing time (in minutes)	1	1	1	1

## steam

*When you microwave food, steam is created as water in the food heats up and evaporates.*

The steam formed during microwave cooking is entirely safe. It has to escape from the microwave to prevent pressure from building up inside the oven. It does this through the vents on the back of the microwave and from around the door.




## condensation

As the steam cools, you may find the condensation gathers in small pools inside your microwave and on the work surface beneath the door and vents.


Always dry the microwave after cooking foods with a high moisture content.

Your microwave is designed to let steam escape from the vents and around the door without microwave energy escaping. (Fig 1)  
There is no danger of microwave energy escaping with the steam.




## product overview



## control panel overview



before use



Accessories			
<p><b>part numbers</b> 252100500504 and 252200200010</p>  <p>Glass Turnable x 1 Turnable Ring x 1</p>	<p><b>part number</b> 256511700007</p>  <p>Grill Rack x 1</p>	<p><b>part number</b> 250900200006</p>  <p>Defrost Rack x 1</p>	<p><b>part number</b> 261800305981</p>  <p>Instruction Manual x 1</p>

## checking your microwave

Check your microwave after unpacking.

**NOTE:** For your safety, the microwave stops if the oven door is opened during cooking. Close the door and press the **start/+30sec** to continue the cooking cycle.

1. Pull handle to open the oven door.  
Put the turntable ring inside the oven and place the glass turntable on top of the ring. The turntable is shaped to sit securely on the spindle. (Fig 1)  
You must always use the glass turntable and turntable ring whenever you use the microwave.  
Place a cup of water on the glass turntable. Make sure the cup is microwave safe - it should not have any decorative metal trim.
2. Close the oven door.
3. Press the **stop/clear** pad to clear any settings that have already been made. (Fig 2)
4. Press the **start/+30sec** once to start a simple 30-second microwave cooking cycle and that allows you to check the operation of the microwave oven.
5. Press the **stop/clear** pad to clear any settings once the checking is complete.




# clock setting

When the microwave is connected to the mains power, the LED display will show **0:00**, and the it will sound once. Please ensure you have set the clock prior to use.

Please follow the steps below to set the clock.

1. Press the **clock/kitchen timer** and the LED display will show **00:00**.
2. Press the **numeric pads (0-9)** to enter the time. For example, to input the current time 12:30, you need to press **1230**. The input hour has to be within 0-23 and the input minutes has to be within 0-59.
3. Press the **clock/kitchen timer** again to complete the clock setting.  
: will start flashing and the time will illuminate.




before use

# setting the child lock

*This feature prevents the electronic operation of the microwave by locking the operation of the control panel until you have cancelled it.*

Please follow the steps below to set the child lock.

1. Press the **stop/clear** pad for 3 seconds and a long tone will sound and the child lock indicator will illuminate to indicate the microwave has set the child lock.
2. To release the child lock, press the **stop/clear** pad again for 3 seconds and a long tone will sound and the child lock indicator will disappear to indicate the microwave has released the child lock.




# microwave cooking

For simple **Microwave Cooking**, follow the steps below.

For instance: If you want to use 80% microwave power to cook for 20 minutes.

1. Press the **microwave** pad once and the LED display will show **P100**. Press the pad again to change the microwave power level to **P80**.
2. Press the **numeric pads (0-9)** to enter the cooking time until the LED display shows **20:00**.
3. Press the **start/+30sec** pad to confirm and start cooking.
4. Press the **stop/clear** pad to stop and hold the cooking. Press again to cancel the setting.

Microwave Button Control		
Order	LED Display	Microwave Power
1	P100	100%
2	P80	80%
3	P50	50%
4	P30	30%
5	P10	10%



operating instructions


# grill or combination cooking

For **Grilling**, follow the steps below.

1. Press the **grill** pad once and the LED display will show **G-1**.
2. Press the **numeric pads (0-9)** to enter the cooking time.
3. Press the **start/+30sec** pad to confirm and start cooking.
4. Press the **stop/clear** pad to stop and hold the cooking. Press again to cancel the setting.

For **Combination Cooking**, follow the steps below.

1. Press the **combi** button once and the LED display will show **C-1**. Press the **combi**. button twice and the LED display will show **C-2** and so forth.
2. Press the **numeric pads (0-9)** to enter the cooking time. The time setting is between 0:05 - 95:00.
3. Press the **start/+30sec** pad to confirm and start cooking.
4. Press the **stop/clear** pad to stop and hold the cooking. Press again to cancel the setting.



Grill Pad Control				
Order	LED Display	Microwave Power	Grill Power	Convection
1	G-1	<b>X</b>	100%	<b>X</b>

**NOTE:** The microwave will sound twice to indicate it has reached the half time for the cooking session, this is normal.

In order to obtain better grilling performance for your food, please turn your food over periodically. Press the **stop/clear** button once to stop cooking and open the door. Then, turn your food over and close the door.


Press the **start/+30sec** button to continue cooking.

Combi Pad Control					
Order	LED Display	Microwave Power	Grill Power	Convection	Cavity Temperature
1	C-1	50%	<b>X</b>	50%	Approximately keeping at 165°C
2	C-2	50%	50%	<b>X</b>	
3	C-3	<b>X</b>	100%	100%	Approximately keeping at 175°C
4	C-4	30%	70%	70%	

Please note that there are only 4 modes of Combination Cooking and their Microwave, Grill and Convection Powers are shown on the table above.

For instance: If you want to do 50% microwave power and 50% grill power cooking (**C-2**) for 10 minutes, please follow the steps below.

1. Press the **combi** pad twice and the LED display will show **C-2**.
2. Press the **numeric pads (0-9)** to enter the cooking time until the LED display shows **10:00**.
3. Press the **start/+30sec** pad to confirm and start cooking.
4. Press the **stop/clear** pad to stop and hold the cooking. Press again to cancel the setting.




operating instructions

# convection cooking (with preheating)

**Convection Cooking** allows you to cook the food like a traditional oven. It is recommended to preheat the oven to the appropriate temperature before placing the food in the oven. Microwave power will not be used.

1. Press the **convex** pad once and the LED display will flash **140**.
2. Keep pressing the **convex** pad until the LED display shows your preferred temperature setting. Press the button each time and the temperature will increase 10°C. The temperature ranges from 140°C to 230°C.
3. Press the **start/+30sec** pad to start preheating. Once the preheating temperature is reached, the oven will sound twice and the LED display will flash the preheating temperature to remind you.
4. Place your food in the oven and close the door. Press the **numeric pads (0-9)** to enter the cooking time. The maximum time setting is 95 minutes.
5. Press the **start/+30sec** pad to confirm and start cooking.


**NOTE:** Cooking time cannot be input until the preheating temperature is reached and the oven door is opened. If the preheating temperature is still below your preferred temperature setting after 30 minutes, the oven will sound twice to remind you to input the cooking time. The cooking time must be input within 5 minutes; otherwise, the oven will stop the preheating, sound 5 times and return to its original display.



## convection cooking (without preheating)

For **Convection Cooking** without preheating, please follow the steps below.  
For instance: If you want to cook your food for 16 minutes at 180°C.

1. Press the **convex** pad once and the LED display will flash **140**.
2. Keep pressing the **convex** pad until the LED display shows **180**. The temperature ranges from 140°C to 230°C.
3. Place your food in the oven and close the door. Press the **numeric pads (0-9)** to enter the cooking time to **16:00**. The maximum time setting is 95 minutes.
4. Press the **start/+30sec** pad to confirm and start cooking.
5. Press the **stop/clear** pad to stop and hold the cooking. Press again to cancel the setting.



operating instructions


## two-stage cooking

For **Two-Stage Cooking**, please follow the steps below.

For instance: If you want to defrost your food for 5 minutes and then to cook it with 80% microwave power for 7 minutes.

**NOTE:** You can set 2 stages for Two-Stage Cooking at maximum. If defrosting is among one of the stages, then it will set as the first stage.

1. Press the **defrost** pad to initiate the two-stage cooking with defrost as the first stage. The LED display will show **d-1**.
2. Press the **numeric pads (0-9)** to enter the defrosting time until the LED display shows **5:00**.
3. Press the **microwave** pad once and the LED display will show **P100**. Press the button again to change the microwave power level to **P80**.
4. Press the **numeric pads (0-9)** to enter the cooking time until the LED display shows **7:00**.
5. Press the **start/+30sec** pad to confirm and start cooking. The microwave oven will sound once to indicate it has started the defrosting count down. The microwave oven will sound again as it starts the microwave cooking (the second stage). Once completed, the microwave oven will sound five times to indicate the completion.
6. Press the **stop/clear** pad to stop and hold the cooking. Press again to cancel the setting.




# memory programme cooking

For **Memory Programme Cooking**, set the clock first and follow the steps below. You may set 3 different memory programmes. For instance: If you want to set a memory cooking programme with 100% microwave power for 5 minutes.

**NOTE:** You can only set 2 stages for Memory Programme Cooking at maximum. If the microwave is disconnected from the mains socket, all the saved memory programmes will be cancelled. You can also set Two-Stage Cooking in Memory Programme Cooking.

1. Press the **memory** pad once and the LED display will show **1**. Press the pad again to enter the next memory programme and the LED display will show **2** and **3**.
  2. a Press the **microwave** pad to select 100% microwave power level.  
b Press the **numeric pads (0-9)** to enter the cooking time until the LED display shows **5:00**.
  3. Press the **memory** pad to save the cooking programme.
- NOTE:** Alternatively, you can press **start/+30sec** pad to save the programme and start cooking automatically.
4. To access the saved programme again, simply press **memory** pad to select the memory programme you want.
  5. Press **start/+30sec** pad to start cooking.



# auto cooking


This feature allows you to cook most of your food based on the food category and the weight. Select the category and choose the default weight of the food. For quick reference of the cooking time and the default weight, please refer to the **Auto Menu** table.

## auto menu

1. Press the **numeric pads (0-9)** to select the Auto Menu programme required. LED display will show , **AUTO** and default weight etc.
2. Press the same numeric pad(s) to select the default weight for your chosen program. Please refer to the Auto Menu table for information.
3. Press the **start/+30sec** to confirm and start cooking.
4. Press the **stop/clear** pad to stop and hold the cooking. Press again to cancel the setting.

*For instance: If you want to cook 350g of fish using Auto Menu program. Please follow the steps below.*

- a. Press the **numeric pad (2)** to select the Auto Menu program for fish. The LED display will show , **AUTO** and 150g.
- b. Press the **numeric pad (2)** for two more times to select the default weight for **fish** program until the LED display shows **350**.
- c. Press the **start/+30sec** pad to confirm and start cooking.



**NOTE:** Cake menu is under convection cooking. Once you confirmed the cooking program, the 180°C pre-heating function will automatically integrate in the process. When the preheating temperature is reached, the oven will sound once. Place the cake in the oven and press the **start/+30sec** button to confirm and start baking the cake for 45 minutes.

**NOTE:** The density and thickness of food can affect its cooking time. Ensure all food is piping hot and cooked thoroughly before serving. It is essential that food is checked during and after the recommended cooking time, even if Auto Menu was used.

**Auto Menu table**

Menu	Weight	Display	Cooking Time	Comments	
A-1 vegetable	150g	150	2'20"	<ul style="list-style-type: none"> <li>Only use suitable microwavable containers and cling film in the microwave oven.</li> <li>Check the cooking regularly to make sure the water does not boil over.</li> </ul>	
	350g	350	4'20"		
	500g	500	6'00"		
A-2 fish	150g	150	2'40"	Make sure food is cooked thoroughly before consuming. Additional cooking time may be required for thicker pieces of fish.	
	250g	250	3'50"		
	350g	350	5'00"		
	450g	450	6'10"		
	650g	650	8'30"		
A-3 meat	150g	150	2'30"	Make sure food is cooked thoroughly before consuming. Additional cooking time may be required for thicker pieces of meat.	
	300g	300	4'10"		
	450g	450	5'50"		
	600g	600	7'30"		
A-4 pasta	50g	50g	18'00"	50g of Pasta + 450ml of Cold Water	<ul style="list-style-type: none"> <li>Only use suitable microwavable containers and cling film in the microwave oven.</li> <li>Check the cooking regularly to make sure the water does not boil over.</li> </ul>
	100g	100g	20'00"	100g of Pasta + 800ml of Cold Water	
	150g	150g	22'00"	150g of Pasta + 1200ml of Cold Water	
A-5 potatoes	1 (~230g)	1	5'00"	For best results, pierce the potatoes' skin before cooking. Once the potatoes are cooked, wrap them in aluminium foil for at least 5 minutes to ensure they are cooked thoroughly.	
	2 (~460g)	2	7'40"		
	3 (~690g)	3	9'40"		
A-6 soup	200ml	200	2'00"	Only use suitable microwavable containers and cling film in the microwave oven. Pierce the film with a fork before cooking.	
	400ml	400	4'00"		
	600ml	600	6'00"		
A-7 roast chicken	500g	500	25'00"	Make sure food is cooked thoroughly before consuming. Additional cooking time may be required for thicker pieces of chicken.	
	750g	750	30'00"		
	1000g	1000	35'00"		
	1200g	1200	40'00"		
A-8 bread	50g	50	7'00"	This setting is designed for re-heating baked bread (not frozen bread dough).	
	100g	100	7'10"		
	150g	150	7'20"		
A-9 cake	475g	475	45'00"	For best results, we recommend using cake mix. Use a tin no larger than 8 inches and the oven will auto preheat the oven at 180°C first. We recommend using a grill rack to support the tin. Check the cake at regular intervals.	
A-10 pizza	200g	200	6'00"	This setting is designed for re-heating cooked pizza slices (not frozen pizza). Additional cooking time may be required for thicker pieces of pizza.	
	300g	300	7'30"		
	400g	400	9'00"		

operating instructions


# reheating

This feature allows you to reheat most of your food based on the food category and the weight. Select the category and choose the default weight of the food.

For quick reference of the cooking time and the default weight, please refer to the Reheating table.

1. Press the **reheat** pad to select the reheating programme required. The LED display will show **h-1, h-2, h-3** and **h-4**.
2. Press the **start/+30sec** pad to confirm the reheating programme. The LED display will show your selected programme.
3. Press the **reheat** pad again to select the default weight of the selected programme. Please refer to the Reheating table for information.
4. Press the **start/+30sec** to confirm and start cooking.
5. Press the **stop/clear** pad to stop and hold the cooking. Press again to cancel the setting.

Menu	Weight	Display	Cooking Time
h-1 (Auto Reheat)	150g	150	1'30"
	250g	250	2'10"
	350g	350	2'50"
	450g	450	3'30"
	600g	600	4'10"
h-2 (Dinner Plate)	250g	250	2'00"
	350g	350	3'10"
	450g	450	4'00"
h-3 (Coffee)	1 (~240ml)	1	1'40"
	2 (~480ml)	2	3'00"
	3 (~720ml)	3	4'00"
h-4 (Roll)	1 (~70g)	1	0'25"
	2 (~140g)	2	0'35"
	3 (~210g)	3	0'45"



# defrosting

This feature allows you to defrost your frozen foods simply by entering the weight or time. You may wish to place the frozen food on a microwave safe plate or dish before placing it on the defrost rack. This is to ensure that any liquids released during defrosting will not spill and dirty the interior of the oven.

## defrost by time


1. Press the **defrost** pad once and the LED display will show ,  and **d-1**.
2. Press the **numeric pads (0-9)** to set the defrosting lead time.

**NOTE:** The maximum setting time is 99 minutes and 99 seconds.

3. Press the **start/+30sec** pad to start defrosting.
4. Press the **stop/clear** pad to stop defrosting or cancel the setting.

## defrost by weight

1. Press the **defrost** pad twice and the LED display will show **d-2**.
2. Press the **numeric pads (0-9)** to enter the weight of your food. The default range is 100g to 2000g.
3. Press the **start/+30sec** pad to start defrosting.
4. Press the **stop/clear** pad to stop and hold the defrosting. Press again to cancel the setting.




**TIPS:** Large items may be frozen in the centre. Therefore, to ensure even thawing, turn them over from time to time and break them into smaller pieces during defrosting. You will need to press the **stop/clear** pad once to hold the defrosting program and open the oven door. After you rotate the food, you need to press the **start/+30sec** pad to re-start defrosting. Place roasts fat-side down or whole poultry breast-side down. Drain liquids during defrosting as the juices from food can get hot and cook the food.

## defrosting ground meat

1. Press the **defrost** pad three times and the LED display will show **d-3**.
2. Press the **numeric pads (0-9)** to enter the weight of your food. The default range is 100g to 2000g.
3. Press the **start/+30sec** pad to start defrosting.
4. Press the **stop/clear** pad to stop and hold the defrosting. Press again to cancel the setting.

## defrosting seafood

1. Press the **defrost** pad four times and the LED display will show **d-4**.
2. Press the **numeric pads (0-9)** to enter the weight of your food. The default range is 100g to 2000g.
3. Press the **start/+30sec** pad to start defrosting.
4. Press the **stop/clear** pad to stop and hold the defrosting. Press again to cancel the setting.



## querying the cooking function

This feature allows you to check and view the current power, time, and pre-set time of your selected cooking programme.

to find out the current cooking power

1. Press the **microwave, convec** or **combi** pad once and the LED display will show the current cooking power while the oven is either microwave, grill, combination, or convection cooking. It will last for 2 - 3 seconds and the oven will then return to its original display.

to find out the time

2. Press the **clock/kitchen timer** pad once and the LED display will show the time while the oven is in cooking state. It will last for 2 - 3 seconds and the oven will then return to its original display.




## kitchen timer function

1. Press the **clock/kitchen timer** pad twice. The LED display will show **00:00** with the first two digits flashing.
2. Press the **numeric pads (0-9)** to enter the correct time. The maximum time setting is 99 minutes and 99 seconds.
3. Press the **start/+30sec** to confirm and the ":" indicator will illuminate.
4. Once the elapsed time is reached, the microwave will sound 5 times and return to its original state.

**NOTE:** When the microwave door is opened, the kitchen timer will pause.

5. Press the **stop/clear** pad to stop and cancel the setting.




# Cleaning your

*Cleaning your microwave after each time you use it will help to prevent  
Unplug your microwave from the mains and wait for  
On the right hand side wall of the cavity is the wave guide cover,  
It is important that this wave guide cover is kept clean at all times.*

The oven walls have a special enamel coating which makes cleaning very easy. Use a soft damp cloth to wipe off any splashes or a paper towel to mop up any spills. Wipe off grease with a damp cloth and a little detergent. Dry thoroughly. As with any oven, if grease is left to accumulate, it can smoke and even catch fire.




Wash the racks in warm water. Do not use very hot water on the baking plate and the shaft which could make them warp.



Treat the glass turntable as you would any glass plate. After you have used it for more than 15 minutes, allow it to cool down before you use it again. Do not wash the turntable in very hot water, this could crack it. Make sure the turntable is dry before you put it back in the oven.

Wash the turntable ring in warm water. Do not use very hot water which could make it warp.

Make sure you keep the outlet grids clean.



Clean behind the door ledge.

Keep the inside of the door clean with a damp cloth. Use warm soapy water for stubborn marks and dry thoroughly. The inside of the door has a special coating and must not be cleaned with abrasive pads or cleaning powders.




# microwave

a build up of stubborn marks that can be difficult to clean.  
it to cool down completely before cleaning.  
microwaves are passed through this to enable your food to cook.  
Wipe it with mild detergent and water and leave to dry.

Be careful not to spill water into the vents.

Keep the front of the oven clean so that the door can close properly.



Do not remove wave guide cover: It is important to keep the cover clean in the same manner as the inside of the oven. If grease is left to accumulate, it can smoke and even catch fire.

Unplug the oven before cleaning the power lead and the oven. Wipe with a damp cloth and leave to dry before plugging it back in.

Use warm soapy water to clean the outside of the oven. Do not use abrasive pads or powders that could scratch the surface.

**NOTE:** Do not remove any fixed parts from the inside of your microwave oven during cleaning or at any other time.

# troubleshooting

*If a problem does occur, it may often be due to something very minor. The following Q & A may be able to resolve the problem.*

## questions and answers

**Q.** *Why doesn't the food seem to cook?*

**A.** Check that:

- the cooking time has been set
- the door is closed
- the mains socket is not overloaded causing the fuse to blow.

**Q.** *Why does the food seem undercooked or overcooked?*

**A.** Check that:

- the correct cooking time has been set
- the correct power setting has been used.

**Q.** *How can I stop eggs from popping?*

**A.** When you cook or poach eggs in the microwave, the yolk can sometimes pop as steam builds up inside it. You can stop the egg from popping by piercing the yolk with a toothpick before cooking. Never cook eggs that are still in their shells.

**Q.** *Why is it so important that I allow standing time after cooking?*

**A.** With microwave cooking, many foods build up enough heat inside them to continue cooking even after they've been taken out of the oven. Because microwave cooking works from the outside of food inwards, standing time lets you cook the centre of the food just right without the outside being overcooked.

**Q.** *Why does my oven sometimes take longer to cook than it says in the recipe?*

**A.** First check that the oven was set just as the recipe said. Cooking times and heat settings are suggestions to help prevent overcooking but differences in the weight, size, shape and starting temperature of food will all affect how long it takes to cook – just as it does with a conventional oven. Use your judgement along with the recipe to check whether the food has been cooked properly.

**Q.** *Why do I get condensation on the inside of the oven door?*

**A.** Condensation is perfectly normal, especially when you are cooking food with a high moisture content such as potatoes.

**Q.** *Does the microwave energy get through the window on the door?*

**A.** No. The door has a special metal screen with holes in that lets you see inside but stops microwave energy from getting out.

**Q.** *Steam comes out of the side of the door and vents. Can microwave energy get out too?*

**A.** No. The door and vents are carefully designed to let steam out during cooking but keep microwave energy in. The gaps are not big enough for microwave energy to escape.

## questions and answers

*Q. What happens if the microwave is switched on while the oven is empty?*

**A.** The microwave will be damaged. Do not switch the microwave on when there is nothing inside the oven. It is a good idea to keep a cup of water in the oven just in case someone accidentally starts the microwave.

*Q. Why doesn't the oven light illuminate?*

**A.** Open the door. If the light does not illuminate, the bulb has probably blown. Call a qualified technician – do not try to change the bulb yourself.

*Q. There are sparks inside the oven when I use the microwave. Will this cause any damage?*

**A.** Yes. Make sure that you are not using any metal utensils and that your containers don't have a metal trim. You must not use metal in your microwave, except foil, when you cook.

*Q. Light is showing through the vents and door. Does this mean the microwave energy can escape?*

**A.** No. It is normal for the light to be visible and is nothing to be concerned about.

*Q. Why do I get interference on my TV and radio when I use the microwave?*

**A.** Microwave ovens use radio waves similar to those received by TVs and radios. You can lessen the interference by moving your microwave further away from the TV or radio.

# specification

<b>Input</b>	230 - 240V ~50Hz
<b>Output</b>	850 - 900 Watts
<b>Microwave Frequency</b>	2450MHz
<b>Outside Dimensions</b>	520mm x 495mm x 325mm (width x deep x height)
<b>Power consumption</b>	
<b>Microwave</b>	1450 - 1600 Watts
<b>Grill</b>	1100 - 1250 Watts
<b>Convection</b>	2500 - 2700 Watts

Complies with EEC directives 89/336/EEC and 92/31/EEC.

Because we continually strive to improve our products, we may change specifications without prior notice. The highest quality requirements are placed on our appliances. However, should a malfunction occur for which you cannot find any information in the operating instructions, please contact the store where you purchased your appliance.



**IMPORTANT INFORMATION FOR CORRECT DISPOSAL OF THE PRODUCT IN ACCORDANCE WITH EC DIRECTIVE 2002/96/EC.**

At the end of its working life, the product must not be disposed of as urban waste.

It must be taken to a special local authority differentiated waste collection centre or to a dealer providing this service.

Disposing of a household appliance separately avoids possible negative consequences for the environment and health deriving from an inappropriate disposal and enables the constituent materials to be recovered to obtain significant savings in energy and resources. As a reminder of the need to dispose of household appliances separately, the product is marked with a crossed-out wheeled dustbin.



Visit [Partmaster.co.uk](http://Partmaster.co.uk) today for the easiest way to buy electrical spares and accessories. With over 1 million spares and accessories available we can deliver direct to your door the very next day. Visit [www.partmaster.co.uk](http://www.partmaster.co.uk) or call 0844 800 3456 (UK customers only) Calls charged at National Rate.

NOTE: If you require a replacement for any of the items listed below, please quote their corresponding part numbers:

Replacement Part	Part Number
glass turntable	252100500504
turntable ring	252200200010
grill rack	256511700007
defrost rack	250900200006
instruction manual	261800305981



**DSG Retail Limited is responsible for after sales service.**

**If you have a query about the product please contact our product support line 0844 561 6263 (Currys) and 08700 118 117 (Pixmania).**

DSG Retail Limited · Maylands Avenue  
Hemel Hempstead · Herts · HP2 7TG · England