

LOGIK

20 Litre Silver Microwave

Instruction Manual
L20MS10



Contents

Unpacking	4
Getting Ready	5
Introducing Microwave Cooking	6
Cooking with a Microwave.....	6
Checking your cooking utensils.....	7
Using Aluminium Foil in Your Microwave.....	7
Microwave Heating Categories	8
Steam.....	9
Condensation.....	9
Product Overview	10
The Main Unit.....	10
The Control Panel	10
Checking Your Microwave.....	11
Clock Setting	12
Setting the Child Lock	13
Microwave Cooking	14
Multi-Stage Cooking	15
Delay Start Cooking (Programme Set in Advance)	16
Defrosting	17
Defrost by Weight.....	17
Defrost by Time	17
Quick Start Cooking	18
Querying the Cooking Function	19
To find out the current cooking setting	19
To find out the preset time.....	19
Cleaning Your Microwave.....	20
Frequently Asked Questions	21
Specification	22
Safety Warnings.....	23

Thank you for purchasing your new Logik Microwave.

These operating instructions will help you use it properly and safely.


We recommend that you spend some time reading this instruction manual in order that you fully understand all the operational features it offers.

Read all the safety instructions carefully before use and keep this instruction manual for future reference.


Unpacking

Remove all packaging from the unit. Retain the packaging. If you dispose of it please do so according to local regulations.

The following items are included:




The Main Unit



Glass Turntable Plate x 1
P.N.: XGALL20MS10P12



Turntable Support x 1
P.N.: XGALL20MS10P11



Instruction Manual x 1
P.N.: L20MS10-002




If items are missing, or damaged please contact Partmaster (UK only).
Tel: 0844 800 3456 for assistance.

Getting Ready


This microwave is designed for home use. It should not be used for commercial catering.

1. After unpacking your microwave, check that it has not been damaged whilst in the box. Make sure there are no dents, and the door closes properly. A damaged microwave could allow microwave energy to escape. Make sure that you have taken out all of the packaging from the inside of the microwave. Please dispose of the plastic wrappings/ bags safely and keep out of the reach of babies and young children.


2. Choose a flat work surface for your microwave away from heat sources such as radiators or fires and away from cold areas. You should allow a 10cm space all around the microwave and 30cm above so that warm air can escape from the vents during cooking – This microwave is not designed to be built in.




3. Plug your microwave into a standard household electrical socket. Avoid using a socket that also has an adaptor and other equipment plugged in. Do not use a multi adaptor.



4. Put the turntable support inside the microwave and place the glass turntable plate on top of the support. The turntable support is shaped to sit securely on the spindle. You must always use the turntable plate and support whenever you use the microwave.



5. To protect your work surface, we recommend that you fix some non-slip cushion buttons (not included) to the underside of the microwave.



Underside View



Remove the turntable plate and turntable support before turning the microwave upside down.


Introducing Microwave Cooking

Always remember the basic safeguards you would follow when using any cooking equipment or handling hot food.

This page gives some of the basic guidelines for microwave cooking. If you are unfamiliar with using a microwave, there is more information at the back of this instruction booklet.

Cooking with a Microwave

- Cooking with a microwave is much faster than conventional cooking and, whilst you should make sure that food is fully cooked, you should be careful not to overcook it.
- Microwave energy can heat unevenly so stirring to distribute heat is very important. Always stir from the outside, inwards.
- If you are cooking a number of individual foods at the same time, such as baked potatoes or small cakes, arrange them evenly on the turntable plate so that they cook evenly. Never stack food in your microwave.
- Turn larger foods such as meat roasts and poultry during cooking so that the top and bottom cook evenly. It is also recommended to turn pieces of meat or poultry, especially if they have not been deboned.
- Meat and poultry which is cooked for 15 minutes or more will brown lightly in its own fat. Anything cooked for a shorter time can be brushed with a browning sauce to give an appetising colour.
- Strips of aluminium foil can be used to cover the thinner pieces of food to stop them overcooking before the thicker parts of the food have had a chance to cook. Use the aluminium foil sparingly and wrap around the food or container carefully to stop it touching the inside of the microwave which could cause sparks.
- Microwaves cook food using microwave energy that is similar to naturally occurring radio waves. Normally, these “waves” would fade as they disappeared into the atmosphere but in a microwave they are concentrated onto food causing it to heat up.
- Microwave energy can not pass through metal – so it can not escape from inside your microwave – but it can pass through materials like glass, porcelain, plastic, and paper. These are the things used to make microwave-safe cooking equipment.
- Microwave - safe cooking equipment will still get hot as the food it contains heats up.
- The microwave energy focuses on the moisture in the food causing lots of tiny vibrations. The vibrations get so great that the moisture – and the food – heat up.



Checking your cooking utensils

Most heat-resistant, non-metallic cooking utensils are safe to use in your microwave. If you are not sure you can use a utensil in your microwave, follow this simple test:

1. Put the utensil into the microwave next to a cup of water – use a cup that you know is microwave safe. Close the door.
2. Turn the microwave on for 30 seconds only.
3. After 30 seconds, carefully check to see if the water has warmed up. If the water has not warmed up but the utensil has, the utensil is not microwave safe and should not be used in the microwave.
4. Do not use your hands to touch the utensil as it may already be hot.



- Never use equipment made of metal, except aluminium foil in your microwave.
- The microwave energy can not pass through the metal so it bounces off and sparks against the inside of the microwave.
- Stop the microwave straight away if any equipment does cause sparks.
- Remember that some crockery has a metal trim around the edge. Even this trim can cause sparks.
- Never use scratched, cracked or damaged glass in a microwave. Damaged glass can explode.

Using Aluminium Foil in Your Microwave

It is safe to use aluminium foil in your microwave as long as you follow these safety guidelines.

As with all metals, microwave energy cannot pass through aluminium foil, but provided you keep the aluminium foil away from the side of the microwave it will not cause sparks and there will not be any damage to your microwave.

Using aluminium foil is a good way of shielding parts of food that you do not want to cook as quickly as others – perhaps where the food is narrower and would otherwise overcook.

Place the aluminium foil over the area you want to shield, taking care that the aluminium foil will not touch the sides of the microwave when the turntable plate rotates. Only use one piece of aluminium foil at a time so that you do not get sparks between the separate pieces.

Follow these guidelines when using aluminium foil in your microwave:

- Remove aluminium foil lids from containers before using in the microwave. Some lids are made of card with a aluminium foil covering – these should be removed too. Use a microwave safe transparent lid if possible.
- Stir food during cooking if the container has a lid or film cover.
- Always use the glass turntable plate.
- Use shallow containers with a large surface area. Do not use containers that are more than 1.25in (3.5cm) deep.
- Use gloves when handling hot aluminium foil containers.
- Do not completely cover food with aluminium foil. The microwave energy cannot pass through the aluminium foil so the food will not cook.
- Do not let aluminium foil touch the inside of the microwave.
- Do not use more than one piece of aluminium foil in the microwave at the same time.

Microwave Heating Categories

Your microwave has been tested and labelled to meet the government's voluntary agreement on the reheating of pre-cooked food.

The heating characteristics and output power levels of microwaves are usually calculated using a relatively large portion of food (a 1000 gram load, IEC 705) but many packs of pre-cooked food are sold in smaller packs, often about 350 grams.

The government, in partnership with food companies and microwave manufacturers, have set up a system of heating categories to help you choose the reheating time for pre-cooked food.




800W is the output power of the microwave.

E is the heating category for your microwave. Check the cooking times for category E on the food's packaging to see how long it should be cooked for. Please see the below example for reference.


To Microwave:

1. Remove outer packaging.
2. Pierce film lid SEVERAL TIMES.
3. Place on a microwaveable plate.
4. Heat on full power.
5. Turn halfway through heating.

	Heating Category		Wattage (IEC705)	
	B	D	650W	750W
	B	D	650W	750W
Full power (in minutes)	2	2	2	2
Turn	Turn		Turn	
Full power (in minutes)	2	1.5	2	1.5
Standing time (in minutes)	1	1	1	1

To Microwave from frozen:

1. Remove outer packaging.
2. Pierce film lid SEVERAL TIMES.
3. Place on a microwaveable plate.
4. Heat on full power.
5. Turn halfway through heating.

	Heating Category		Wattage (IEC705)	
	B	D	650W	750W
	B	D	650W	750W
Full power (in minutes)	3	2.5	3	2.5
Turn	Turn		Turn	
Full power (in minutes)	4	3.5	4	3.5
Standing time (in minutes)	1	1	1	1

Steam


When you microwave food, steam is created as water in the food heats up and evaporates.

The steam formed during microwave cooking is entirely safe. It has to escape from the microwave to prevent pressure from building up inside the microwave. It does this through the vents on the back of the microwave and from around the door.

Condensation


As the steam cools, you may find that condensation gathers in small pools inside your microwave and on the work surface beneath the door and vents. Always dry the microwave after cooking foods with a high moisture content.

Your microwave is designed to let steam escape from the vents and around the door without microwave energy escaping. There is no danger of microwave energy escaping with the steam.




Product Overview

The Main Unit



The Control Panel




Checking your Microwave


Check your microwave after unpacking.



For your safety, the microwave stops if the door is opened during cooking. Close the door and press the **Start** button to continue the cooking cycle.



1. Press the **Door Open** button to open the door.
2. Place a cup of water on the glass turntable plate. Make sure the cup is microwave safe (it should not have any decorative metal trim).
3. Close the door.
4. Press the **Stop/Clear** button to clear any settings that have already been made.
5. Press the **Quick Start** button twice and then press the **Start** button to start a simple 30-second microwave cooking cycle. This allows you to check the operation of the microwave.
6. When the cooking cycle has finished, the water should be hot (be careful when you take the cup out of the microwave). Press the **Stop/Clear** button to clear any settings.



Clock Setting


When the microwave is connected to the mains power, the LED display will show "1:01" and the microwave will sound once. Please ensure that you have set the clock prior to use.

Please follow the steps below to set the clock.

1. Press the **Clock** button and then press **Stop/Clear** button and the LED display will show ": 0".
2. Press the **Numeric** buttons and enter the time. For example, to input the current time "12:30", you need to press the "1", "2", "3", "0". The input time has to be between 12:00 and 11:59.
3. Press the **Clock** button again to complete the clock setting. ":" will start flashing and the time will illuminate to confirm that the clock setting is complete.



- This is a 12-hour clock. When the microwave is connected to the mains power for the first time or when the power is resumed after a power interruption, the LED display will show "1:01". To re-set the clock, simply follow the above 3 steps.
- In the process of clock setting, if the **Stop/Clear** button is pressed or if there is no operation within 1 minute, the microwave will go back to the previous status automatically.
- If the clock needs to be reset, please repeat steps 1 to 3.
- To find out the current time while the microwave is operating, press the **Clock** button. It will last for 2-3 seconds and then return to its original display.



Setting the Child Lock

This feature prevents the electronic operation of the microwave by locking the operation of the control panel until you have cancelled it.

Please follow the steps below to set the child lock.

1. Press the **Stop/Clear** button for 3 seconds and the microwave will sound. The child lock indicator will illuminate on the LED display to indicate that the microwave has set the child lock.
2. To release the child lock, press the **Stop/Clear** button again for 3 seconds and the microwave will sound. The child lock indicator will disappear from the LED display to indicate that the microwave has released the child lock.



Microwave Cooking

For simple **Microwave Cooking**, follow the steps below.

For instance, if you want to use 80% microwave power to cook for 20 minutes.


1. Press the **Microwave** button once and the LED display will show "P10". Press the **Numeric** buttons to change the microwave power level from **P0** to **P10**. For example, select 80% microwave power by pressing "8". The LED display will show "P8".
2. Press the **Time** button once and then press the **Numeric** buttons to enter the cooking time. For example, press the **Time** button once and then enter the cooking time by pressing "2", "0", "0", "0". The LED display will show "20:00".



The default microwave power is 100% (P10). You may skip Step 3 if you plan to use 100% microwave power for cooking.

3. Press the **Start** button to confirm and start cooking.
4. Press the **Stop/Clear** button to pause the cooking. Press the **Stop/Clear** button again to cancel the setting.

Power Level + Numeric Buttons Control		
Order	LED Display	Microwave Power
10	P10	100%
9	P9	90%
8	P8	80%
7	P7	70%
6	P6	60%
5	P5	50%
4	P4	40%
3	P3	30%
2	P2	20%
1	P1	10%
0	P0	0%



- When removing food from the microwave, please ensure that the microwave has stopped.
- Operating the microwave without food in it can result in overheating and damage the magnetron.



When P0 is selected, no microwave power will be present. This setting is for deodorising purposes only.

Multi-Stage Cooking

For **Multi-Stage Cooking**, please follow the steps below.

For instance: If you want to defrost food for 5 minutes, and then cook it with 100% microwave power for 5 minutes, and then cook it with 80% microwave power for 7 minutes.



You can set a maximum of 3 stages for Multi-Stage Cooking only when the time defrosting is set as the first stage. The microwave will sound and pause after 2/3 of the running time has elapsed. Open the door and rotate the food. Close the microwave and then press the **Start** button to restart defrosting. If you required two-stage cooking only, simply follow step 2-9. Quick start cooking and weight defrosting are not available in Multi-Stage Cooking.

1. Press the **Defrost By Time** button and the LED display will show ": 0". Press the **Numeric** buttons to enter the defrosting leadtime by pressing "5", "0", "0", and the LED display will show "5:00".




Do not press the **Start** button at this stage.

2. Press the **2-Stage Cooking** button to set up the second stage cooking. The LED display will show "15".
3. Press the **Microwave** button once and the LED display will show "P10".
4. Press the **Time** button and then enter the cooking time by pressing "5", "0", "0". The LED display will show "5:00".



Do not press the **Start** button at this stage.

5. Press the **2-Stage Cooking** button to set up the third stage cooking. The LED display will show "25".
6. Press the **Microwave** button once and then select the 80% microwave power by pressing "8". The LED display will show "P8".
7. Press the **Time** button once and then enter the cooking time by pressing "7", "0", "0". The LED display will show "7:00".
8. Press the **Start** button to confirm. The microwave will sound once to indicate it has started the defrosting. The microwave will sound again as it starts the microwave cooking (the second and the third cooking stages). Upon completion, the microwave will sound three times.
9. Press the **Stop/Clear** button to pause the cooking. Press the **Stop/Clear** button again to cancel the setting.



Delay Start Cooking (Programme Set in Advance)

For **Delay Start Cooking**, follow the steps below.

For instance: The current time is 12 o'clock (noon) and you want to cook with 80% microwave power for 5 minutes in 1 hour and 30 minutes time.




- You can set a maximum of 2 stages for Delay Start Cooking. Defrosting cannot be set as one of those stages.
- Ensure the door is closed prior to setting the programme.
- Ensure that the clock has been set correctly before using Delay Start Cooking.

1. Press the **Microwave** button once and then select the 80% microwave power by pressing "**8**". The LED display will show "**P8**".
2. Press the **Time** button once and then enter the cooking time by pressing "**5**", "**0**", "**0**". The LED display will show "**5:00**".




Do not press the **Start** button at this stage.

3. Press the **Preset** button to preset the starting time for the cooking. The LED display will show "**:0**".
4. Enter the time by pressing "**1**", "**3**", "**0**". The LED display will show "**1:30**".
5. Press the **Start** button to complete the setting, and the  will flash. The microwave will sound 3 times when the count down reaches the starting time and cooking will start automatically.
6. Press the **Stop/Clear** button to cancel the setting.



To find out the preset time, press the **Preset** button once while the microwave is still in the preset state. It will last for 2-3 seconds and then return to its original display.



Defrosting

This feature allows you to defrost your frozen foods simply by entering the weight or time.

Defrost by Weight


1. Press the **Defrost By Weight** button and the LED display will show "d1", "d2", and "d3".
2. Press the **Numeric (0-9)** buttons to enter the weight of your food.

Programme	LED Display	Maximum Weight	Maximum Time Required
Meat	d1	2300g	53:40
Poultry	d2	4000g	80:00
Seafood	d3	900g	19:30

3. Press the **Start** button to confirm and start defrosting.
4. Press the **Stop/Clear** button to pause the defrosting. Press the **Stop/Clear** button again to cancel the setting.

Defrost by Time

1. Press the **Defrost By Time** button to defrost food by time.
2. Press the **Numeric (0-9)** buttons to enter the defrosting leadtime.
3. Press the **Start** button to confirm and start defrosting.
4. Press the **Stop/Clear** button to pause the defrosting. Press the **Stop/Clear** button again to cancel the setting.



- The microwave will sound and pause after 2/3 of the running time has elapsed. Open the door and rotate the food. Close the door and then press the **Start** button to restart defrosting.
- Large items may be frozen in the centre. To ensure even thawing, turn them over from time to time and break them into smaller pieces during defrosting.
- Place roasts fat-side down or whole poultry breasts side down.
- Drain liquids during defrosting as the juices from food can get hot and cook the food.


Quick Start Cooking

This feature allows you to quickly cook your food for 15 seconds with 100% microwave power. Please follow the steps below.

1. Press the **Quick Start** button to start the quick start cooking of 15 seconds.

Press	Cooking Time
Once	15 seconds
Twice	30 seconds
Three Times	1 minute
Four Times	2 minutes

2. Press the **Stop/Clear** button to pause the cooking. Press the **Stop/Clear** button again to cancel the setting.




Querying the Cooking Function

This feature allows you to check and view the current cooking settings.

To find out the current cooking setting

1. Press the **Microwave** button once and the LED display will show the current cooking setting while the microwave is in microwave cooking. It will last for 3 seconds and then return to its original display.




Cleaning your Microwave

Cleaning your microwave each time you use it will help to prevent a build up of stubborn marks that can be difficult to clean.

Unplug your microwave from the mains and wait for it to completely cool down before cleaning.

On the right hand side wall of the cavity is the wave guide cover. Microwaves are passed through this to enable your food to cook. It is important that this wave guide cover is kept clean at all times. Wipe it with mild detergent and water and leave to dry.



- 1** The microwave walls have a special enamel coating which makes cleaning very easy. Use a soft damp cloth to wipe off any splashes or a paper towel to mop up any spills. Wipe off grease with a damp cloth and a little detergent. Dry thoroughly. If grease is left to accumulate, it can smoke and even catch fire.
- 2** Make sure you keep the outlet grids clean.
- 3** Keep the front of the microwave clean so that the door can close properly.
- 4** Be careful not to spill water into the vents.
- 5** Do not remove the wave guide cover: It is important to keep cover clean in the same manner as the inside of the microwave. If grease is left to accumulate, it can smoke and even catch fire.
- 6** Keep the inside of the door clean with a damp cloth. Use warm soapy water for stubborn marks and dry thoroughly. The inside of the door has a special coating and must not be cleaned with abrasive pads or cleaning powders.
- 7** Clean behind the door ledge.
- 8** Use warm soapy water to clean the outside of the microwave. Do not use abrasive buttons or powders that could scratch the surface.
- 9** Unplug the microwave before cleaning the power lead and the microwave. Wipe with a damp cloth and leave to dry before plugging it back in.
- 10** Treat the glass turntable plate as you would any glass plate. After you have used it for more than 15 minutes, allow it to cool down before you use it again. Do not wash the glass turntable plate in very hot water, doing so could crack it. Wash the turntable support in warm water. Do not use very hot water which could make it warp. Make sure the glass turntable plate and turntable support are dry before you put them back in the microwave.



Do not remove any fixed parts from the inside of your microwave during cleaning or at any other time.

Frequently Asked Questions

If a problem does occur, it may often be due to something very minor. The following Q & A may be able to resolve the problem.

Questions	Answers
Why doesn't the food seem to cook?	Check that: <ul style="list-style-type: none"> • the cooking time has been set • the door is closed • the mains socket is not overloaded causing the fuse to blow.
Why does the food seem undercooked or overcooked?	Check that: <ul style="list-style-type: none"> • the correct cooking time has been set • the correct power setting has been used.
How can I stop eggs from popping?	When you bake or poach eggs in the microwave, the yolk can sometimes pop as steam builds up inside it. You can stop the egg from popping by piercing the yolk with a toothpick before cooking. Never cook eggs that are still in their shells.
Why is it so important that I allow standing time after cooking?	With microwave cooking, many foods build up enough heat inside them to continue cooking even after they've been taken out of the microwave. Because microwave cooking works from the outside of food inwards, standing time lets you cook the centre of the food without the outside being overcooked.
Why does my microwave sometimes take longer to cook than it says in the recipe?	First check that the microwave was set just as the recipe said. Cooking times and heat settings are suggestions to help prevent overcooking but differences in the weight, size, shape and starting temperature of food will all affect how long it takes to cook – just as it does with a conventional oven. Use your judgement along with the recipe to check whether the food has been cooked properly.
Why do I get condensation on the inside of the door?	Condensation is perfectly normal, especially when you are cooking food with a high moisture content such as potatoes.
Does the microwave energy get through the window on the door?	No. The door has a special metal screen with holes in that lets you see inside but stops microwave energy from getting out.
Steam comes out of the side of the door and vents. Can microwave energy get out too?	No. The door and vents are carefully designed to let steam out during cooking but keep microwave energy in. The gaps are not big enough for microwave energy to escape.
What happens if the microwave is switched on while the microwave is empty?	The microwave will be damaged. Do not switch the microwave on when there's nothing inside the microwave. It is a good idea to keep a cup of water in the microwave just in case someone accidentally starts the microwave.
Why doesn't the microwave's light illuminate?	Open the door. If the light does not illuminate, the bulb has probably blown. Call a qualified technician – do not try to change the bulb yourself.
There are sparks inside the microwave when I use the microwave. Will this cause any damage?	Yes. Make sure that you are not using any metal utensils and that your containers don't have a metal trim. You must not use metal in your microwave when you cook (except aluminium foil).
Light is showing through the vents and door. Does this mean the microwave energy can escape?	No. It is normal for the light to be visible and is nothing to be concerned about.
Why do I get interference on my TV and radio when I use the microwave?	Microwaves use radio waves similar to those received by TVs and radios. You can lessen the interference by moving your microwave further away from the TV or radio.

Specification

Model	L20MS10
Input	230 - 240V~ 50Hz
Microwave Output	700 - 800 Watts
Microwave Frequency	2450MHz
Outside Dimensions (width x deep x height)	452mm x 370mm x 262mm
Power consumption	
Microwave Input	1250 - 1350 Watts

Complies with EC directives 2004/108/EC and 2006/95/EC.

We continually strive to improve our products. Features and specifications may change without prior notice.

Safety Warnings

General Safety

- Switch off and unplug before fitting or removing tools/attachments, after use and before cleaning.
- Keep your fingers away from moving parts and fitted attachments.
- Never use a damaged appliance.
- Never operate the appliance when it is empty.
- Keep the mains cable out of reach from children.
- Keep the unit, mains cable and plug away from water.
- Never exceed the maximum capacities.
- When using an attachment, read the accompanying safety instructions.
- Take care when lifting this appliance as it is heavy.
- You should always have your appliance checked by a qualified technician if it has been dropped or damaged to ensure it is safe to use.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Only use the appliance for its intended domestic use.

Maintenance of your microwave

WARNING : It is hazardous for anyone other than a qualified technician to carry out any service or repair operation which involves the removal of a cover that gives protection against exposure to microwave energy.

WARNING : If the door or door seals are damaged, the microwave must not be operated until it has been repaired by a qualified technician.

- If smoke is observed, switch off or unplug the microwave and keep the door closed in order to stifle any flames.
- If the mains cable is damaged, it must be replaced by a service agent or a qualified technician.
- If you have a pacemaker, please contact your doctor before using a microwave.

Microwave Use

- This microwave is not intended for commercial use.
- It should never be used for drying clothes or for other non-food purposes.
- The microwave should not be left unattended when in use.
- The temperature of accessible surfaces may be high when the microwave is operating.
- To prevent high moisture content gathering inside the microwave cavity, open the door immediately after the cooking function has stopped to allow steam to escape.
- Only use utensils that are suitable for microwave use.
- Care should be taken when using paper, plastic, wooden or other combustible materials in the microwave as they can catch fire.
- Oil & fat for deep frying should not be heated in the microwave.
- Only use cling film designed for microwave use and take extra care when removing the film to avoid steam burns.
- Only heat popcorn that has been designed for microwave use.

Cooking Use

- As the power of different microwaves can vary considerably, care must be taken when first using this microwave as it may cook faster than expected.
- Do not leave the microwave unattended during use.
- Take care when cooking food with a high sugar or fat content, such as Christmas pudding or fruitcake. The sugar or fat can overheat and in some cases catch fire.

WARNING : Only allow children to use the microwave without supervision when adequate instructions have given so that the child is able to use the microwave in a safe way and understands the hazards of improper use; DO NOT assume that because a child has mastered one cooking skill he/she can cook everything without close supervision. The microwave MUST NOT be treated nor used like a toy.

Fire!

In the event of fire:

- Keep the microwave door closed.
- Turn off the power.
- Unplug the microwave from the mains power.

First Aid

Treat scalding by:

- Quickly placing the scald under cold running water for at least 10 minutes.
- Cover with a clean dry dressing. Do not use creams, oils or lotions.

Cleaning your Microwave

The microwave should be cleaned regularly and food deposits removed. Failure to maintain the microwave in a clean condition can affect the life of the microwave and possibly result in a hazardous situation. (See cleaning your microwave)

Do not use these in your Microwave

- Metal objects are not to be used in the microwave. These include:
 - Metal cooking utensils.
 - Metal plates or trays
 - Wine twist ties
 - Crockery with metal trims
 - Meat thermometer
- Never use equipment made of metal, except aluminium foil in your microwave. The microwave energy cannot pass through the metal so it bounces off and sparks against the inside of the microwave.
- Stop the microwave straight away if any equipment is causing sparks.
- Remember that some crockery has a metal trim around the edge. Even this trim can cause sparks.

Containers

WARNING : Pressure will build up in sealed containers and can cause them to explode. Therefore, do not use the following in your microwave:

- Sealed containers
 - Sealed jars
 - Nuts
 - Capped bottles
 - Hard-boiled eggs
 - Vacuum containers
 - Eggs in their shells
- Always pierce the skin of fruit and vegetables, such as potatoes.
 - Never use scratched, cracked or damaged glass in a microwave. Damaged glass can explode.
 - When heating food in plastic or paper containers, keep an eye on the microwave due to the possibility of ignition.

Delayed Boiling

Liquids heated in a microwave can boil up when removing them from the microwave.

Take the following precautions :

- Always stir liquids, before and after cooking.
- Allow them to stand.
- Use containers that are wider at the top than at the bottom.

Preparing food for Babies

Extra care must be taken when preparing food or drink for babies and small children.

- Always test the food or liquid temperature before feeding it to the baby.
- When using a baby bottle, ensure the teat is removed before heating.
- When warming milk, ensure the bottle is shaken.



Caution!



Hot Surface

During cooking the outer surface will become hot. Do not touch the outer casing of the microwave. Care should be taken not to store any items on top of your microwave.

Earthing Instructions

WARNING: THIS APPLIANCE MUST BE EARTHED.

- This appliance is equipped with a mains cable having an earthed plug.
- The plug must be plugged into an appropriate mains socket that is installed and earthed in accordance with all local standards and requirements.

Warning!

- Improper connection of the appliance-earthing conductor can result in a risk of an electric shock.
- Check with a qualified electrician or service representative if you are in doubt whether the appliance is properly earthed.
- Never modify the plug provided with the appliance.
- If the plug does not fit properly in the mains socket, have a qualified electrician install a proper mains socket.

NOTE: If you require a replacement for any of the items listed below, please quote their corresponding part numbers:

Replacement Part	Part Number
Glass Turntable Plate	XGALL20MS10P12
Turntable Support	XGALL20MS10P11



DSG Retail Limited is responsible for after sales service.

If you have a query about the product please contact our product support line 0844 561 6263 (Currys).



Visit Partmaster.co.uk today for the easiest way to buy electrical spares and accessories. With over 1 million spares and accessories available we can deliver direct to your door the very next day. Visit www.partmaster.co.uk or call 0844 800 3456 (UK customers only) Calls charged at National Rate.



This symbol on the product or in the instructions means that your electrical and electronic equipment should be disposed at the end of its life separately from your household waste. There are separate collection systems for recycling in the EU.

For more information, please contact the local authority or your retailer where you purchased the product.

DSG Retail Ltd • Maylands Avenue • Hemel Hempstead
Herts • HP2 7TG • England

(P.N.: L20MS10-002)

